

Table F-10* (continued)
Escape codes

Escape code	Function
Escape C or c	Moves cursor down one line; exits from escape mode
Escape D or d	Moves cursor up one line; exits from escape mode
Escape E or e	Clears to end of line; exits from escape mode
Escape F or f	Clears to bottom of window; exits from escape mode
Escape I or i or Escape Up Arrow	Moves the cursor up one line; remains in escape mode (see text)
Escape J or j or Escape Left Arrow	Moves the cursor left one space; remains in escape mode (see text)
Escape K or k or Escape Right Arrow	Moves the cursor right one space; remains in escape mode (see text)
Escape M or m or Escape Down Arrow	Moves the cursor down one line; remains in escape mode (see text)
Escape 4	If 80-column firmware is active, switches to 40-column mode; sets links to BASICIN and BASICOUT; restores normal window size; exits from escape mode
Escape 8	If 80-column firmware is active, switches to 80-column mode; sets links to BASICIN and BASICOUT; restores normal window size; exits from escape mode
Escape Control-D	Disables control characters; only carriage return, line feed, BELL, and backspace have an effect when printed
Escape Control-E	Reactivates control characters
Escape Control-Q	If 80-column firmware is active, deactivates 80-column firmware; sets links to KEYIN and COUT1; restores normal window size; exits from escape mode

* Table 3-6