

Editing with GETLN	63
Cancel line	63
Backspace	63
Retype	64
Monitor firmware support	64
I/O firmware support	68

## **Chapter 4 Memory Organization 73**

Main memory map	74
RAM memory allocation	76
Reserved memory pages	77
Page zero	77
The 65C02 stack	78
The input buffer	78
Link-address storage	78
The display buffers	78
Bank-switched memory	82
Setting bank switches	83
Reading bank switches	86
Auxiliary memory and firmware	86
Memory mode switching	88
Auxiliary-memory subroutines	91
Moving data to auxiliary memory	92
Transferring control to auxiliary memory	93
The reset routine	94
The cold-start procedure	95
The warm-start procedure	95
Forced cold start	96
The reset vector	96
Automatic self-test	98

## **Chapter 5 Using the Monitor 99**

Invoking the Monitor	100
Syntax of Monitor commands	101
Monitor memory commands	102
Examining memory contents	102
Memory dump	102
Changing memory contents	105
Changing one byte	105
Changing consecutive locations	106
ASCII input mode	106
Moving data in memory	107
Comparing data in memory	109
Searching for bytes in memory	110
Examining and changing registers	110