




↑
Long Strut




↑
Short Strut



↑
Right
Angle
Strut




↑
Left
Angle
Strut






Inner
Wheel
Sections

Fuselage
Spacer



glue wing connector here

Right Wing



glue wing connector here

Left Wing



